


# CHAPTER 1

## Introduction



*Viscous shear stresses between a moving layer of fluid and fluid within a cavity produce a swirl motion within the cavity. (Particles in oil; time exposure.)*  
(Photograph by B. R. Munson.)

### LEARNING OBJECTIVES

---

After completing this chapter, you should be able to:

- determine the dimensions and units of physical quantities.
- identify the key fluid properties used in the analysis of fluid behavior.
- calculate common fluid properties given appropriate information.
- explain effects of fluid compressibility.
- use the concepts of viscosity, vapor pressure and surface tension.

**F**luid mechanics is that discipline within the broad field of applied mechanics concerned with the behavior of liquids and gases at rest or in motion. This field of mechanics obviously encompasses a vast array of problems that may vary from the study of blood flow in the capillaries (which are only a few microns in diameter) to the flow of crude oil across Alaska through an 800-mile-long, 4-ft-diameter pipe. Fluid mechanics principles are needed to explain why airplanes are made streamlined with smooth surfaces for the most efficient flight, whereas golf balls are made with rough surfaces (dimpled) to increase their efficiency. It is very likely that during your career as an engineer you will be involved in the analysis and design of systems that require a good understanding of fluid mechanics. It is hoped that this introductory text will provide a sound foundation of the fundamental aspects of fluid mechanics.

## 1.1 Some Characteristics of Fluids

One of the first questions we need to explore is—what is a fluid? Or we might ask—what is the difference between a solid and a fluid? We have a general, vague idea of the difference. A solid is “hard” and not easily deformed, whereas a fluid is “soft” and is easily deformed (we can readily move through air). Although quite descriptive, these casual observations of the differences between solids and fluids are not very satisfactory from a scientific or engineering point of view. A more specific distinction is based on how materials deform under the action of an external load. A *fluid is defined as a substance that deforms continuously when acted on by a shearing stress of any magnitude*. A shearing stress (force per unit area) is created whenever a tangential force acts on a surface. When common solids such as steel or other metals are acted on by a shearing stress, they will initially deform (usually a very small deformation), but they will not continuously deform (flow). However, common fluids such as water, oil, and air satisfy the definition of a fluid—that is, they will flow when acted on by a shearing stress. Some materials, such as slurries, tar, putty, toothpaste, and so on, are not easily classified since they will behave as a solid if the applied shearing stress is small, but if the stress exceeds some critical value, the substance will flow. The study of such materials is called *rheology* and does not fall within the province of classical fluid mechanics.

Although the molecular structure of fluids is important in distinguishing one fluid from another, because of the large number of molecules involved, it is not possible to study the behavior of individual molecules when trying to describe the behavior of fluids at rest or in motion. Rather, we characterize the behavior by considering the average, or macroscopic, value of the quantity of interest, where the average is evaluated over a small volume containing a large number of molecules.

We thus assume that all the fluid characteristics we are interested in (pressure, velocity, etc.) vary continuously throughout the fluid—that is, we treat the fluid as a *continuum*. This concept will certainly be valid for all the circumstances considered in this text.

## 1.2 Dimensions, Dimensional Homogeneity, and Units

Since we will be dealing with a variety of fluid characteristics in our study of fluid mechanics, it is necessary to develop a system for describing these characteristics both *qualitatively* and *quantitatively*. The qualitative aspect serves to identify the nature, or type, of the characteristics (such as length, time, stress, and velocity), whereas the quantitative aspect provides a numerical measure of the characteristics. The quantitative description requires both a number and a standard by which various quantities can be compared. A standard for length might be a meter or foot, for time an hour or second, and for mass a slug or kilogram. Such standards are called *units*, and several systems of units are in common use as described in the following section. The qualitative description is conveniently given in terms of certain *primary quantities*, such as length,  $L$ , time,  $T$ , mass,  $M$ , and temperature,  $\Theta$ . These primary quantities can then be used to provide a qualitative description of any other *secondary quantity*, for example, area  $\doteq L^2$ , velocity  $\doteq LT^{-1}$ , density  $\doteq ML^{-3}$ , and so on, where the symbol  $\doteq$  is used to indicate the *dimensions* of the secondary quantity in terms of the primary quantities. Thus, to describe qualitatively a velocity,  $V$ , we would write

$$V \doteq LT^{-1}$$

and say that “the dimensions of a velocity equal length divided by time.” The primary quantities are also referred to as *basic dimensions*.

For a wide variety of problems involving fluid mechanics, only the three basic dimensions,  $L$ ,  $T$ , and  $M$ , are required. Alternatively,  $L$ ,  $T$ , and  $F$  could be used, where  $F$  is the basic dimension of force. Since Newton's law states that force is equal to mass times acceleration, it follows that  $F \doteq MLT^{-2}$  or  $M \doteq FL^{-1}T^2$ . Thus, secondary quantities expressed in terms of  $M$  can be expressed in terms of  $F$  through the relationship just given. For example, stress,  $\sigma$ , is a force per unit area, so that  $\sigma \doteq FL^{-2}$ , but an equivalent dimensional equation is  $\sigma \doteq ML^{-1}T^{-2}$ . Table 1.1 provides a list of dimensions for a number of common physical quantities.

All theoretically derived equations are *dimensionally homogeneous*—that is, the dimensions of the left side of the equation must be the same as those on the right side, and all additive separate terms must have the same dimensions. We accept as a fundamental premise

■ **TABLE 1.1**  
Dimensions Associated with Common Physical Quantities

	<i>FLT</i> System	<i>MLT</i> System
Acceleration	$LT^{-2}$	$LT^{-2}$
Angle	$F^0L^0T^0$	$M^0L^0T^0$
Angular acceleration	$T^{-2}$	$T^{-2}$
Angular velocity	$T^{-1}$	$T^{-1}$
Area	$L^2$	$L^2$
Density	$FL^{-4}T^2$	$ML^{-3}$
Energy	$FL$	$ML^2T^{-2}$
Force	$F$	$MLT^{-2}$
Frequency	$T^{-1}$	$T^{-1}$
Heat	$FL$	$ML^2T^{-2}$
Length	$L$	$L$
Mass	$FL^{-1}T^2$	$M$
Modulus of elasticity	$FL^{-2}$	$ML^{-1}T^{-2}$
Moment of a force	$FL$	$ML^2T^{-2}$
Moment of inertia (area)	$L^4$	$L^4$
Moment of inertia (mass)	$FLT^2$	$ML^2$
Momentum	$FT$	$MLT^{-1}$
Power	$FLT^{-1}$	$ML^2T^{-3}$
Pressure	$FL^{-2}$	$ML^{-1}T^{-2}$
Specific heat	$L^2T^{-2}\Theta^{-1}$	$L^2T^{-2}\Theta^{-1}$
Specific weight	$FL^{-3}$	$ML^{-2}T^{-2}$
Strain	$F^0L^0T^0$	$M^0L^0T^0$
Stress	$FL^{-2}$	$ML^{-1}T^{-2}$
Surface tension	$FL^{-1}$	$ML^{-2}$
Temperature	$\Theta$	$\Theta$
Time	$T$	$T$
Torque	$FL$	$ML^{-2}T^{-2}$
Velocity	$LT^{-1}$	$LT^{-1}$
Viscosity (dynamic)	$FL^{-2}T$	$ML^{-1}T^{-1}$
Viscosity (kinematic)	$L^2T^{-1}$	$L^2T^{-1}$
Volume	$L^3$	$L^3$
Work	$FL$	$ML^2T^{-2}$

that all equations describing physical phenomena must be dimensionally homogeneous. For example, the equation for the velocity,  $V$ , of a uniformly accelerated body is

$$V = V_0 + at \quad (1.1)$$

where  $V_0$  is the initial velocity,  $a$  the acceleration, and  $t$  the time interval. In terms of dimensions the equation is

$$LT^{-1} = LT^{-1} + LT^{-1}$$

and thus Eq. 1.1 is dimensionally homogeneous.

Some equations that are known to be valid contain constants having dimensions. The equation for the distance,  $d$ , traveled by a freely falling body can be written as

$$d = 16.1t^2 \quad (1.2)$$

and a check of the dimensions reveals that the constant must have the dimensions of  $LT^{-2}$  if the equation is to be dimensionally homogeneous. Actually, Eq. 1.2 is a special form of the well-known equation from physics for freely falling bodies,

$$d = \frac{gt^2}{2} \quad (1.3)$$

in which  $g$  is the acceleration of gravity. Equation 1.3 is dimensionally homogeneous and valid in any system of units. For  $g = 32.2 \text{ ft/s}^2$  the equation reduces to Eq. 1.2, and thus Eq. 1.2 is valid only for the system of units using feet and seconds. Equations that are restricted to a particular system of units can be denoted as *restricted homogeneous equations*, as opposed to equations valid in any system of units, which are *general homogeneous equations*. The concept of dimensions also forms the basis for the powerful tool of *dimensional analysis*, which is considered in detail in Chapter 7.

**Note to the users of this text.** All of the examples in the text use a consistent problem-solving methodology which is similar to that in other engineering courses such as statics. Each example highlights the key elements of analysis: **Given**, **Find**, **Solution**, and **Comment**.

The **Given** and **Find** are steps that ensure the user understands what is being asked in the problem and explicitly list the items provided to help solve the problem.

The **Solution** step is where the equations needed to solve the problem are formulated and the problem is actually solved. In this step, there are typically several other tasks that help to set up the solution and are required to solve the problem. The first is a drawing of the problem; where appropriate, it is always helpful to draw a sketch of the problem. Here the relevant geometry and coordinate system to be used as well as features such as control volumes, forces and pressures, velocities and mass flow rates are included. This helps in gaining a visual understanding of the problem. Making appropriate assumptions to solve the problem is the second task. In a realistic engineering problem-solving environment, the necessary assumptions are developed as an integral part of the solution process. Assumptions can provide appropriate simplifications or offer useful constraints, both of which can help in solving the problem. Throughout the examples in this text, the necessary assumptions are embedded within the **Solution** step, as they are in solving a real-world problem. This provides a realistic problem-solving experience.

The final element in the methodology is the **Comment**. For the examples in the text, this section is used to provide further insight into the problem or the solution. It can also be a point in the analysis at which certain questions are posed. For example: Is the answer reasonable, and does it make physical sense? Are the final units correct? If a certain parameter were changed, how would the answer change? Adopting the above type of methodology will aid in the development of problem-solving skills for fluid mechanics, as well as other engineering disciplines.


**EXAMPLE 1.1** Restricted and General Homogeneous Equations

**GIVEN** A commonly used equation for determining the volume rate of flow,  $Q$ , of a liquid through an orifice located in the side of a tank as shown in Fig. E1.1 is

$$Q = 0.61 A \sqrt{2gh}$$

where  $A$  is the area of the orifice,  $g$  is the acceleration of gravity, and  $h$  is the height of the liquid above the orifice.

**FIND** Investigate the dimensional homogeneity of this formula.



■ FIGURE E1.1

**SOLUTION**

The dimensions of the various terms in the equation are

$$Q = \text{volume/time} \doteq L^3 T^{-1}$$

$$A = \text{area} \doteq L^2$$

$$g = \text{acceleration of gravity} \doteq L T^{-2}$$

$$h = \text{height} \doteq L$$

These terms, when substituted into the equation, yield the dimensional form

$$(L^3 T^{-1}) \doteq (0.61)(L^2)(\sqrt{2})(L T^{-2})^{1/2}(L)^{1/2}$$

or

$$(L^3 T^{-1}) \doteq [(0.61)\sqrt{2}](L^3 T^{-1})$$

It is clear from this result that the equation is dimensionally homogeneous (both sides of the formula have the same dimensions of  $L^3 T^{-1}$ ), and the numbers (0.61 and  $\sqrt{2}$ ) are dimensionless.

**COMMENT** If we were going to use this relationship repeatedly, we might be tempted to simplify it by replacing  $g$  with its standard value of  $32.2 \text{ ft/s}^2$  and rewriting the formula as

$$Q = 4.90 A \sqrt{h} \quad (1)$$

A quick check of the dimensions reveals that

$$L^3 T^{-1} \doteq (4.90)(L^{5/2})$$

and, therefore, the equation expressed as Eq. 1 can only be dimensionally correct if the number, 4.90, has the dimensions of  $L^{1/2} T^{-1}$ . Whenever a number appearing in an equation or formula has dimensions, it means that the specific value of the number will depend on the system of units used. Thus, for the case being considered with feet and seconds used as units, the number 4.90 has units of  $\text{ft}^{1/2}/\text{s}$ . Equation 1 will only give the correct value for  $Q$  (in  $\text{ft}^3/\text{s}$ ) when  $A$  is expressed in square feet and  $h$  in feet. Thus, Eq. 1 is a *restricted* homogeneous equation, whereas the original equation is a *general* homogeneous equation that would be valid for any consistent system of units. A quick check of the dimensions of the various terms in an equation is a useful practice and will often be helpful in eliminating errors—that is, as noted previously, all physically meaningful equations must be dimensionally homogeneous. We have briefly alluded to units in this example, and this important topic will be considered in more detail in the next section.

**1.2.1 Systems of Units**

In addition to the qualitative description of the various quantities of interest, it is generally necessary to have a quantitative measure of any given quantity. For example, if we measure the width of this page in the book and say that it is 10 units wide, the statement has no meaning until the unit of length is defined. If we indicate that the unit of length is a meter, and define the meter as some standard length, a unit system for length has been established (and a numerical value can be given to the page width). In addition to length, a unit must be established for each of the remaining basic quantities (force, mass, time, and temperature). There are several systems of units in use and we shall consider two systems that are commonly used in engineering.

**British Gravitational (BG) System.** In the BG system the unit of length is the foot (ft), the time unit is the second (s), the force unit is the pound (lb), and the temperature unit is the degree Fahrenheit ( $^{\circ}\text{F}$ ), or the absolute temperature unit is the degree Rankine ( $^{\circ}\text{R}$ ), where

$$^{\circ}\text{R} = ^{\circ}\text{F} + 459.67$$

The mass unit, called the *slug*, is defined from Newton's second law (force = mass  $\times$  acceleration) as

$$1 \text{ lb} = (1 \text{ slug})(1 \text{ ft/s}^2)$$

This relationship indicates that a 1-lb force acting on a mass of 1 slug will give the mass an acceleration of  $1 \text{ ft/s}^2$ .

The weight,  $W$  (which is the force due to gravity,  $g$ ) of a mass,  $m$ , is given by the equation

$$W = mg$$

and in BG units

$$W (\text{lb}) = m (\text{slugs}) g (\text{ft/s}^2)$$

Since the earth's standard gravity is taken as  $g = 32.174 \text{ ft/s}^2$  (commonly approximated as  $32.2 \text{ ft/s}^2$ ), it follows that a mass of 1 slug weighs 32.2 lb under standard gravity.

## F l u i d s i n t h e N e w s

**How long is a foot?** Today, in the United States, the common length *unit* is the *foot*, but throughout antiquity the unit used to measure length has quite a history. The first length units were based on the lengths of various body parts. One of the earliest units was the Egyptian cubit, first used around 3000 B.C. and defined as the length of the arm from elbow to extended fingertips. Other measures followed with the foot simply taken as the length of a man's foot. Since this length obviously varies from person to person it was often "standardized" by using the length of the current reigning royalty's foot. In 1791

a special French commission proposed that a new universal length unit called a meter (metre) be defined as the distance of one-quarter of the earth's meridian (north pole to the equator) divided by 10 million. Although controversial, the meter was accepted in 1799 as the standard. With the development of advanced technology, the length of a meter was redefined in 1983 as the distance traveled by light in a vacuum during the time interval of  $1/299,792,458 \text{ s}$ . The foot is now defined as 0.3048 meters. Our simple rulers and yardsticks indeed have an intriguing history. ■

**International System (SI).** In 1960, the Eleventh General Conference on Weights and Measures, the international organization responsible for maintaining precise uniform standards of measurements, formally adopted the *International System of Units* as the international standard. This system, commonly termed SI, has been adopted worldwide and is widely used (although certainly not exclusively) in the United States. It is expected that the long-term trend will be for all countries to accept SI as the accepted standard, and it is imperative that engineering students become familiar with this system. In SI the unit of length is the meter (m), the time unit is the second (s), the mass unit is the kilogram (kg), and the temperature unit is the kelvin (K). Note that there is no degree symbol used when expressing a temperature in kelvin units. The Kelvin temperature scale is an absolute scale and is related to the Celsius (centigrade) scale ( $^{\circ}\text{C}$ ) through the relationship

$$\text{K} = ^{\circ}\text{C} + 273.15$$

Although the Celsius scale is not in itself part of SI, it is common practice to specify temperatures in degrees Celsius when using SI units.

The force unit, called the newton (N), is defined from Newton's second law as

$$1 \text{ N} = (1 \text{ kg})(1 \text{ m/s}^2)$$

Thus, a 1-N force acting on a 1-kg mass will give the mass an acceleration of  $1 \text{ m/s}^2$ . Standard gravity in SI is  $9.807 \text{ m/s}^2$  (commonly approximated as  $9.81 \text{ m/s}^2$ ) so that a 1-kg mass weighs 9.81 N under standard gravity. Note that weight and mass are different, both qualitatively and

■ **TABLE 1.2**  
**Conversion Factors from BG Units to SI Units**

(See inside of back cover.)

■ **TABLE 1.3**  
**Conversion Factors from SI Units to BG Units**

(See inside of back cover.)

quantitatively! The unit of *work* in SI is the joule (J), which is the work done when the point of application of a 1-N force is displaced through a 1-m distance in the direction of the force. Thus,

$$1 \text{ J} = 1 \text{ N} \cdot \text{m}$$

The unit of *power* is the watt (W) defined as a joule per second. Thus,

$$1 \text{ W} = 1 \text{ J/s} = 1 \text{ N} \cdot \text{m/s}$$

Prefixes for forming multiples and fractions of SI units are commonly used. For example, the notation kN would be read as “kilonewtons” and stands for  $10^3 \text{ N}$ . Similarly, mm would be read as “millimeters” and stands for  $10^{-3} \text{ m}$ . The centimeter is not an accepted unit of length in the SI system, and for most problems in fluid mechanics in which SI units are used, lengths will be expressed in millimeters or meters.

*In this text we will use the BG system and SI for units.* Approximately one-half the problems and examples are given in BG units and one-half in SI units. Tables 1.2 and 1.3 provide conversion factors for some quantities that are commonly encountered in fluid mechanics, and these tables are located on the inside of the back cover. Note that in these tables (and others) the numbers are expressed by using computer exponential notation. For example, the number  $5.154 \text{ E} + 2$  is equivalent to  $5.154 \times 10^2$  in scientific notation, and the number  $2.832 \text{ E} - 2$  is equivalent to  $2.832 \times 10^{-2}$ . More extensive tables of conversion factors for a large variety of unit systems can be found in Appendix E.

## F l u i d s i n t h e N e w s

**Units and space travel** A NASA spacecraft, the Mars Climate Orbiter, was launched in December 1998 to study the Martian geography and weather patterns. The spacecraft was slated to begin orbiting Mars on September 23, 1999. However, NASA officials lost communication with the spacecraft early that day, and it is believed that the spacecraft broke apart or overheated because it came too close to the surface of Mars.

Errors in the maneuvering commands sent from earth caused the Orbiter to sweep within 37 miles of the surface rather than the intended 93 miles. The subsequent investigation revealed that the errors were due to a simple mix-up in *units*. One team controlling the Orbiter used SI units whereas another team used BG units. This costly experience illustrates the importance of using a consistent system of units. ■

## 1.3 Analysis of Fluid Behavior

The study of fluid mechanics involves the same fundamental laws you have encountered in physics and other mechanics courses. These laws include Newton’s laws of motion, conservation of mass, and the first and second laws of thermodynamics. Thus, there are strong similarities between the general approach to fluid mechanics and to rigid-body and deformable-body solid mechanics.

The broad subject of fluid mechanics can be generally subdivided into *fluid statics*, in which the fluid is at rest, and *fluid dynamics*, in which the fluid is moving. In subsequent chapters we will consider both of these areas in detail. Before we can proceed, however, it will be necessary to define and discuss certain fluid *properties* that are intimately related to fluid behavior. In the following several sections, the properties that play an important role in the analysis of fluid behavior are considered.

## 1.4 Measures of Fluid Mass and Weight

### 1.4.1 Density

The *density* of a fluid, designated by the Greek symbol  $\rho$  (rho), is defined as its mass per unit volume. Density is typically used to characterize the mass of a fluid system. In the BG system,  $\rho$  has units of slugs/ft<sup>3</sup> and in SI the units are kg/m<sup>3</sup>.

The value of density can vary widely between different fluids, but for liquids, variations in pressure and temperature generally have only a small effect on the value of  $\rho$ . The small change in the density of water with large variations in temperature is illustrated in Fig. 1.1. Tables 1.4 and 1.5 list values of density for several common liquids. The density of water at 60° F is 1.94 slugs/ft<sup>3</sup> or 999 kg/m<sup>3</sup>. The large difference between those two values illustrates the importance of paying attention to units! Unlike liquids, the density of a gas is strongly influenced by both pressure and temperature, and this difference is discussed in the next section.

The *specific volume*,  $v$ , is the *volume* per unit mass and is therefore the reciprocal of the density—that is,


$$v = \frac{1}{\rho} \quad (1.4)$$

This property is not commonly used in fluid mechanics but is used in thermodynamics.

### 1.4.2 Specific Weight

The *specific weight* of a fluid, designated by the Greek symbol  $\gamma$  (gamma), is defined as its *weight* per unit volume. Thus, specific weight is related to density through the equation

$$\gamma = \rho g \quad (1.5)$$



■ FIGURE 1.1 Density of water as a function of temperature.



■ TABLE 1.4

Approximate Physical Properties of Some Common Liquids (BG Units)

(See inside of front cover.)

■ TABLE 1.5

Approximate Physical Properties of Some Common Liquids (SI Units)

(See inside of front cover.)

where  $g$  is the local acceleration of gravity. Just as density is used to characterize the mass of a fluid system, the specific weight is used to characterize the weight of the system. In the BG system,  $\gamma$  has units of  $\text{lb/ft}^3$  and in SI the units are  $\text{N/m}^3$ . Under conditions of standard gravity ( $g = 32.174 \text{ ft/s}^2 = 9.807 \text{ m/s}^2$ ), water at  $60^\circ \text{ F}$  has a specific weight of  $62.4 \text{ lb/ft}^3$  and  $9.80 \text{ kN/m}^3$ . Tables 1.4 and 1.5 list values of specific weight for several common liquids (based on standard gravity). More complete tables for water can be found in Appendix B (Tables B.1 and B.2).

### 1.4.3 Specific Gravity

The *specific gravity* of a fluid, designated as  $SG$ , is defined as the ratio of the density of the fluid to the density of water at some specified temperature. Usually the specified temperature is taken as  $4^\circ \text{ C}$  ( $39.2^\circ \text{ F}$ ), and at this temperature the density of water is  $1.94 \text{ slugs/ft}^3$  or  $1000 \text{ kg/m}^3$ . In equation form specific gravity is expressed as

$$SG = \frac{\rho}{\rho_{\text{H}_2\text{O}@4^\circ\text{C}}} \quad (1.6)$$

and since it is the *ratio* of densities, the value of  $SG$  does not depend on the system of units used. For example, the specific gravity of mercury at  $20^\circ \text{ C}$  is 13.55, and the density of mercury can thus be readily calculated in either BG or SI units through the use of Eq. 1.6 as

$$\rho_{\text{Hg}} = (13.55)(1.94 \text{ slugs/ft}^3) = 26.3 \text{ slugs/ft}^3$$

or

$$\rho_{\text{Hg}} = (13.55)(1000 \text{ kg/m}^3) = 13.6 \times 10^3 \text{ kg/m}^3$$

It is clear that density, specific weight, and specific gravity are all interrelated, and from a knowledge of any one of the three the others can be calculated.

## 1.5 Ideal Gas Law

Gases are highly compressible in comparison to liquids, with changes in gas density directly related to changes in pressure and temperature through the equation

$$p = \rho RT \quad (1.7)$$

where  $p$  is the absolute pressure,  $\rho$  the density,  $T$  the absolute temperature,<sup>1</sup> and  $R$  is a gas constant. Equation 1.7 is commonly termed the *perfect* or *ideal gas law*, or the *equation of*

<sup>1</sup>We will use  $T$  to represent temperature in thermodynamic relationships, although  $T$  is also used to denote the basic dimension of time.

Since  $\delta a = U \delta t$  it follows that

$$\delta\beta = \frac{U \delta t}{b}$$

Note that in this case,  $\delta\beta$  is a function not only of the force  $P$  (which governs  $U$ ) but also of time. We consider the *rate* at which  $\delta\beta$  is changing, and define the *rate of shearing strain*,  $\dot{\gamma}$ , as

$$\dot{\gamma} = \lim_{\delta t \rightarrow 0} \frac{\delta\beta}{\delta t}$$

which in this instance is equal to

$$\dot{\gamma} = \frac{U}{b} = \frac{du}{dy}$$

A continuation of this experiment would reveal that as the shearing stress,  $\tau$ , is increased by increasing  $P$  (recall that  $\tau = P/A$ ), the rate of shearing strain is increased in direct proportion—that is

$$\tau \propto \dot{\gamma}$$

or

$$\tau \propto \frac{du}{dy}$$

This result indicates that for common fluids, such as water, oil, gasoline, and air, the shearing stress and rate of shearing strain (velocity gradient) can be related with a relationship of the form

$$\tau = \mu \frac{du}{dy} \quad (1.8)$$

where the constant of proportionality is designated by the Greek symbol  $\mu$  (mu) and is called the **absolute viscosity**, *dynamic viscosity*, or simply the *viscosity* of the fluid. In accordance with Eq. 1.8, plots of  $\tau$  versus  $du/dy$  should be linear with the slope equal to the viscosity as illustrated in Fig. 1.3. The actual value of the viscosity depends on the particular fluid, and for a particular fluid the viscosity is also highly dependent on temperature as illustrated in Fig. 1.3 with the two curves for water. Fluids for which the shearing stress is *linearly* related to the rate of shearing strain (also referred to as rate of angular deformation) are designated as **Newtonian fluids**. Fortunately, most common fluids, both liquids and gases, are Newtonian. A more general formulation of Eq. 1.8, which applies to more complex flows of Newtonian fluids, is given in Section 6.8.1.

Fluids for which the shearing stress is not linearly related to the rate of shearing strain are designated as *non-Newtonian fluids*. It is beyond the scope of this book to consider the behavior of such fluids, and we will only be concerned with Newtonian fluids.



V1.3 Capillary tube viscometer




V1.4 Non-Newtonian behavior

## Fluids in the News

**A vital fluid** In addition to air and water, another fluid that is essential for human life is blood. Blood is an unusual fluid consisting of red blood cells that are disk-shaped, about 8 microns in diameter, suspended in plasma. As you would suspect, since blood is a suspension, its mechanical behavior is that of a *non-Newtonian* fluid. Its density is only slightly higher than that of water, but its typical apparent *viscosity* is significantly higher than that of water at the same temperature. It is difficult to measure the viscosity of blood since it is a non-Newtonian fluid and the viscosity is a function of the shear

rate. As the shear rate is increased from a low value, the apparent viscosity decreases and approaches asymptotically a constant value at high shear rates. The “asymptotic” value of the viscosity of normal blood is 3 to 4 times the viscosity of water. The viscosity of blood is not routinely measured like some biochemical properties such as cholesterol and triglycerides, but there is some evidence indicating that the viscosity of blood may play a role in the development of cardiovascular disease. If this proves to be true, viscosity could become a standard variable to be routinely measured. (See Problem 1.24.) ■



■ **FIGURE 1.3** Linear variation of shearing stress with rate of shearing strain for common fluids.

From Eq. 1.8 it can be readily deduced that the dimensions of viscosity are  $FTL^{-2}$ . Thus, in BG units viscosity is given as  $lb \cdot s/ft^2$  and in SI units as  $N \cdot s/m^2$ . Values of viscosity for several common liquids and gases are listed in Tables 1.4 through 1.7. A quick glance at these tables reveals the wide variation in viscosity among fluids. Viscosity is only mildly dependent on pressure, and the effect of pressure is usually neglected. However, as mentioned previously, and as illustrated in Appendix B (Figs. B.1 and B.2), viscosity is very sensitive to temperature.

Quite often viscosity appears in fluid flow problems combined with the density in the form

$$\nu = \frac{\mu}{\rho}$$

This ratio is called the *kinematic viscosity* and is denoted with the Greek symbol  $\nu$  (nu). The dimensions of kinematic viscosity are  $L^2/T$ , and the BG units are  $ft^2/s$  and SI units are  $m^2/s$ . Values of kinematic viscosity for some common liquids and gases are given in Tables 1.4 through 1.7. More extensive tables giving both the dynamic and kinematic viscosities for water and air can be found in Appendix B (Tables B.1 through B.4), and graphs showing the variation in both dynamic and kinematic viscosity with temperature for a variety of fluids are also provided in Appendix B (Figs. B.1 and B.2).

Although in this text we are primarily using BG and SI units, dynamic viscosity is often expressed in the metric CGS (centimeter-gram-second) system with units of  $dyne \cdot s/cm^2$ . This combination is called a *poise*, abbreviated P. In the CGS system, kinematic viscosity has units of  $cm^2/s$ , and this combination is called a *stoke*, abbreviated St.

### EXAMPLE 1.3 Viscosity and Dimensionless Quantities

**GIVEN** A dimensionless combination of variables that is important in the study of viscous flow through pipes is called the *Reynolds number*,  $Re$ , defined as  $\rho VD/\mu$  where  $\rho$  is the fluid density,  $V$  the mean fluid velocity,  $D$  the pipe diameter, and  $\mu$  the fluid viscosity. A Newtonian fluid having a viscosity of  $0.38 \text{ N} \cdot \text{s}/\text{m}^2$  and a specific gravity of 0.91

flows through a 25-mm-diameter pipe with a velocity of 2.6 m/s.

**FIND** Determine the value of the Reynolds number using

- SI units and
- BG units.

## SOLUTION

(a) The fluid density is calculated from the specific gravity as

$$\rho = SG \rho_{H_2O@4^\circ C} = 0.91 (1000 \text{ kg/m}^3) = 910 \text{ kg/m}^3$$

and from the definition of the Reynolds number

$$\begin{aligned} Re &= \frac{\rho V D}{\mu} = \frac{(910 \text{ kg/m}^3)(2.6 \text{ m/s})(25 \text{ mm})(10^{-3} \text{ m/mm})}{0.38 \text{ N}\cdot\text{s/m}^2} \\ &= 156 (\text{kg}\cdot\text{m/s}^2)/\text{N} \end{aligned}$$

However, since  $1 \text{ N} = 1 \text{ kg}\cdot\text{m/s}^2$  it follows that the Reynolds number is unitless (dimensionless)—that is,

$$Re = 156 \quad (\text{Ans})$$

**COMMENT** The value of any dimensionless quantity does not depend on the system of units used if all variables that make up the quantity are expressed in a consistent set of units. To check this we will calculate the Reynolds number using BG units.

(b) We first convert all the SI values of the variables appearing in the Reynolds number to BG values by using the conversion factors from Table 1.3. Thus,

$$\begin{aligned} \rho &= (910 \text{ kg/m}^3)(1.940 \times 10^{-3}) = 1.77 \text{ slugs/ft}^3 \\ V &= (2.6 \text{ m/s})(3.281) = 8.53 \text{ ft/s} \\ D &= (0.025 \text{ m})(3.281) = 8.20 \times 10^{-2} \text{ ft} \\ \mu &= (0.38 \text{ N}\cdot\text{s/m}^2)(2.089 \times 10^{-2}) = 7.94 \times 10^{-3} \text{ lb}\cdot\text{s/ft}^2 \end{aligned}$$

and the value of the Reynolds number is

$$\begin{aligned} Re &= \frac{(1.77 \text{ slugs/ft}^3)(8.53 \text{ ft/s})(8.20 \times 10^{-2} \text{ ft})}{7.94 \times 10^{-3} \text{ lb}\cdot\text{s/ft}^2} \\ &= 156 (\text{slug}\cdot\text{ft/s}^2)/\text{lb} = 156 \quad (\text{Ans}) \end{aligned}$$

since  $1 \text{ lb} = 1 \text{ slug}\cdot\text{ft/s}^2$ .

**COMMENT** The values from part (a) and part (b) are the same, as expected. Dimensionless quantities play an important role in fluid mechanics, and the significance of the Reynolds number, as well as other important dimensionless combinations, will be discussed in detail in Chapter 7. It should be noted that in the Reynolds number it is actually the ratio  $\mu/\rho$  that is important, and this is the property that we have defined as the kinematic viscosity.

## EXAMPLE 1.4 Newtonian Fluid Shear Stress

**GIVEN** The velocity distribution for the flow of a Newtonian fluid between two wide, parallel plates (see Fig. E1.4) is given by the equation

$$u = \frac{3V}{2} \left[ 1 - \left( \frac{y}{h} \right)^2 \right]$$

where  $V$  is the mean velocity. The fluid has a viscosity of  $0.04 \text{ lb}\cdot\text{s/ft}^2$ . Also,  $V = 2 \text{ ft/s}$  and  $h = 0.2 \text{ in.}$

## SOLUTION

For this type of parallel flow the shearing stress is obtained from Eq. 1.8.

$$\tau = \mu \frac{du}{dy} \quad (1)$$

Thus, if the velocity distribution,  $u = u(y)$ , is known, the shearing stress can be determined at all points by evaluating the velocity gradient,  $du/dy$ . For the distribution given


$$\frac{du}{dy} = -\frac{3Vy}{h^2} \quad (2)$$

(a) Along the bottom wall  $y = -h$  so that (from Eq. 2)

$$\frac{du}{dy} = \frac{3V}{h}$$

**FIND** Determine

- the shearing stress acting on the bottom wall and
- the shearing stress acting on a plane parallel to the walls and passing through the centerline (midplane).



■ FIGURE E1.4

and therefore the shearing stress is

$$\begin{aligned} \tau_{\text{bottom wall}} &= \mu \left( \frac{3V}{h} \right) = \frac{(0.04 \text{ lb}\cdot\text{s/ft}^2)(3)(2 \text{ ft/s})}{(0.2 \text{ in.})(1 \text{ ft}/12 \text{ in.})} \\ &= 14.4 \text{ lb/ft}^2 \text{ (in direction of flow)} \quad (\text{Ans}) \end{aligned}$$

**COMMENT** This stress creates a drag on the wall. Since the velocity distribution is symmetrical, the shearing stress along the upper wall would have the same magnitude and direction.

(b) Along the midplane where  $y = 0$ , it follows from Eq. 2 that

$$\frac{du}{dy} = 0$$

and thus the shearing stress is

$$\tau_{\text{midplane}} = 0 \quad (\text{Ans})$$

**COMMENT** From Eq. 2 we see that the velocity gradient (and therefore the shearing stress) varies linearly with  $y$  and in this particular example varies from 0 at the center of the channel to  $14.4 \text{ lb/ft}^2$  at the walls. For the more general case the actual variation will, of course, depend on the nature of the velocity distribution.

## 1.7 Compressibility of Fluids

### 1.7.1 Bulk Modulus

An important question to answer when considering the behavior of a particular fluid is how easily can the volume (and thus the density) of a given mass of the fluid be changed when there is a change in pressure? That is, how compressible is the fluid? A property that is commonly used to characterize compressibility is the *bulk modulus*,  $E_v$ , defined as



$$E_v = -\frac{dp}{dV/V} \quad (1.9)$$

where  $dp$  is the differential change in pressure needed to create a differential change in volume,  $dV$ , of a volume  $V$ , as shown by the figure in the margin. The negative sign is included since an increase in pressure will cause a decrease in volume. Because a decrease in volume of a given mass,  $m = \rho V$ , will result in an increase in density, Eq. 1.9 can also be expressed as

$$E_v = \frac{dp}{d\rho/\rho} \quad (1.10)$$

The bulk modulus (also referred to as the *bulk modulus of elasticity*) has dimensions of pressure,  $FL^{-2}$ . In BG units values for  $E_v$  are usually given as  $\text{lb/in.}^2$  (psi) and in SI units as  $\text{N/m}^2$  (Pa). Large values for the bulk modulus indicate that the fluid is relatively incompressible—that is, it takes a large pressure change to create a small change in volume. As expected, values of  $E_v$  for common liquids are large (see Tables 1.4 and 1.5).

Since such large pressures are required to effect a change in volume, we conclude that liquids can be considered as *incompressible* for most practical engineering applications. As liquids are compressed the bulk modulus increases, but the bulk modulus near atmospheric pressure is usually the one of interest. The use of bulk modulus as a property describing compressibility is most prevalent when dealing with liquids, although the bulk modulus can also be determined for gases.



## Fluids in the News

**This water jet is a blast** Usually liquids can be treated as incompressible fluids. However, in some applications the *compressibility* of a liquid can play a key role in the operation of a device. For example, a water pulse generator using compressed water has been developed for use in mining operations. It can fracture rock by producing an effect comparable to a conventional explosive such as gunpowder. The device uses the energy stored in a water-filled accumulator to generate an ultrahigh-pressure water pulse ejected through a 10- to 25-mm-diameter discharge valve. At the ultrahigh pressures used (300 to 400 MPa,

or 3000 to 4000 atmospheres), the water is compressed (i.e., the volume reduced) by about 10 to 15%. When a fast-opening valve within the pressure vessel is opened, the water expands and produces a jet of water that upon impact with the target material produces an effect similar to the explosive force from conventional explosives. Mining with the water jet can eliminate various hazards that arise with the use of conventional chemical explosives such as those associated with the storage and use of explosives and the generation of toxic gas by-products that require extensive ventilation. (See Problem 1.43.) ■


### 1.7.2 Compression and Expansion of Gases

When gases are compressed (or expanded), the relationship between pressure and density depends on the nature of the process. If the compression or expansion takes place under constant temperature conditions (*isothermal process*), then from Eq. 1.7

$$\frac{p}{\rho} = \text{constant} \quad (1.11)$$

If the compression or expansion is frictionless and no heat is exchanged with the surroundings (*isentropic process*), then

$$\frac{p}{\rho^k} = \text{constant} \quad (1.12)$$



where  $k$  is the ratio of the specific heat at constant pressure,  $c_p$ , to the specific heat at constant volume,  $c_v$  (i.e.,  $k = c_p/c_v$ ). The two specific heats are related to the gas constant,  $R$ , through the equation  $R = c_p - c_v$ . The pressure-density variations for isothermal and isentropic conditions are illustrated in the margin figure. As was the case for the ideal gas law, the pressure in both Eqs. 1.11 and 1.12 must be expressed as an absolute pressure. Values of  $k$  for some common gases are given in Tables 1.6 and 1.7, and for air over a range of temperatures, in Appendix B (Tables B.3 and B.4). It is clear that in dealing with gases greater attention will need to be given to the effect of compressibility on fluid behavior. However, as discussed in Section 3.8, gases can often be treated as incompressible fluids if the changes in pressure are small.

### EXAMPLE 1.5 Isentropic Compression of a Gas

**GIVEN** A cubic foot of air at an absolute pressure of 14.7 psi is compressed isentropically to  $\frac{1}{2}$  ft<sup>3</sup>.

**FIND** What is the final pressure?

#### SOLUTION

For an isentropic compression

$$\frac{p_i}{\rho_i^k} = \frac{p_f}{\rho_f^k}$$

where the subscripts  $i$  and  $f$  refer to initial and final states, respectively. Since we are interested in the final pressure,  $p_f$ , it follows that


$$p_f = \left(\frac{\rho_f}{\rho_i}\right)^k p_i$$

As the volume,  $V$ , is reduced by one-half, the density must double, since the mass,  $m = \rho V$ , of the gas remains constant. Thus, with  $k = 1.40$  for air

$$p_f = (2)^{1.40}(14.7 \text{ psi}) = 38.8 \text{ psi (abs)} \quad (\text{Ans})$$

**COMMENT** By repeating the calculations for various values of the ratio of the final volume to the initial volume,  $V_f/V_i$ , the results shown in Fig. E1.5 are obtained. Note that even though air is often considered to be easily compressed (at least compared to liquids), it takes considerable pressure to significantly

reduce a given volume of air as is done in an automobile engine where the compression ratio is on the order of  $V_f/V_i = 1/8 = 0.125$ .



■ FIGURE E1.5

### 1.7.3 Speed of Sound

Another important consequence of the compressibility of fluids is that disturbances introduced at some point in the fluid propagate at a finite velocity. For example, if a fluid is flowing in a pipe and a valve at the outlet is suddenly closed (thereby creating a localized disturbance), the effect of the valve closure is not felt instantaneously upstream. It takes a finite time for the increased pressure created by the valve closure to propagate to an upstream location. Similarly, a loud speaker diaphragm causes a localized disturbance as it vibrates, and the small change in pressure created by the motion of the diaphragm is propagated through the air with a finite velocity. The velocity at which these small disturbances propagate is called the *acoustic velocity* or the *speed of sound*,  $c$ . It can be shown that the speed of sound is related to changes in pressure and density of the fluid medium through the equation

$$c = \sqrt{\frac{dp}{d\rho}} \quad (1.13)$$

or in terms of the bulk modulus defined by Eq. 1.10

$$c = \sqrt{\frac{E_v}{\rho}} \quad (1.14)$$

Because the disturbance is small, there is negligible heat transfer and the process is assumed to be isentropic. Thus, the pressure–density relationship used in Eq. 1.13 is that for an isentropic process.


For gases undergoing an isentropic process,  $E_v = kp$ , so that

$$c = \sqrt{\frac{kp}{\rho}}$$

and making use of the ideal gas law, it follows that

$$c = \sqrt{kRT} \quad (1.15)$$

Thus, for ideal gases the speed of sound is proportional to the square root of the absolute temperature. The speed of sound in air at various temperatures can be found in Appendix B (Tables B.3 and B.4). Equation 1.14 is also valid for liquids, and values of  $E_v$  can be used to determine the speed of sound in liquids. As shown by the figure in the margin, the speed of sound in water is much higher than in air. If a fluid were truly incompressible ( $E_v = \infty$ ) the speed of sound would be infinite. The speed of sound in water for various temperatures can be found in Appendix B (Tables B.1 and B.2).



## EXAMPLE 1.6 Speed of Sound and Mach Number

**GIVEN** A jet aircraft flies at a speed of 550 mph at an altitude of 35,000 ft, where the temperature is  $-66^\circ\text{F}$  and the specific heat ratio is  $k = 1.4$ .

**FIND** Determine the ratio of the speed of the aircraft,  $V$ , to that of the speed of sound,  $c$ , at the specified altitude.

### SOLUTION

From Eq. 1.15 the speed of sound can be calculated as

$$\begin{aligned} c &= \sqrt{kRT} \\ &= \sqrt{(1.40)(1716 \text{ ft}\cdot\text{lb}/\text{slug}\cdot^\circ\text{R})(-66 + 460)^\circ\text{R}} \\ &= 973 \text{ ft/s} \end{aligned}$$

Since the air speed is


$$V = \frac{(550 \text{ mi/hr})(5280 \text{ ft/mi})}{(3600 \text{ s/hr})} = 807 \text{ ft/s}$$

the ratio is

$$\frac{V}{c} = \frac{807 \text{ ft/s}}{973 \text{ ft/s}} = 0.829 \quad (\text{Ans})$$

**COMMENT** This ratio is called the *Mach number*,  $Ma$ . If  $Ma < 1.0$  the aircraft is flying at *subsonic* speeds, whereas for  $Ma > 1.0$  it is flying at *supersonic* speeds. The Mach number is an important dimensionless parameter used in the study of the flow of gases at high speeds and will be further discussed in Chapters 7 and 9.

By repeating the calculations for different temperatures, the results shown in Fig. E1.6 are obtained. Because the speed of sound increases with increasing temperature, for a constant airplane speed, the Mach number decreases as the temperature increases.



■ FIGURE E1.6

## 1.8 Vapor Pressure


It is a common observation that liquids such as water and gasoline will evaporate if they are simply placed in a container open to the atmosphere. Evaporation takes place because some liquid molecules at the surface have sufficient momentum to overcome the intermolecular cohesive forces and escape into the atmosphere. As shown in the figure in the margin, if the lid on a completely liquid-filled, closed container is raised (without letting any air in), a pressure will develop in the space as a result of the vapor that is formed by the escaping molecules. When an equilibrium condition is reached so that the number of molecules leaving the surface is equal to the number entering, the vapor is said to be saturated and the pressure the vapor exerts on the liquid surface is termed the *vapor pressure*,  $p_v$ .

Since the development of a vapor pressure is closely associated with molecular activity, the value of vapor pressure for a particular liquid depends on temperature. Values of vapor pressure for water at various temperatures can be found in Appendix B (Tables B.1 and B.2), and the values of vapor pressure for several common liquids at room temperatures are given in Tables 1.4 and 1.5. *Boiling*, which is the formation of vapor bubbles within a fluid mass, is initiated when the absolute pressure in the fluid reaches the vapor pressure.

An important reason for our interest in vapor pressure and boiling lies in the common observation that in flowing fluids it is possible to develop very low pressure due to the fluid motion, and if the pressure is lowered to the vapor pressure, boiling will occur. For example, this phenomenon may occur in flow through the irregular, narrowed passages of a valve or pump. When vapor bubbles are formed in a flowing liquid, they are swept along into regions of higher pressure where they suddenly collapse with sufficient intensity to actually cause structural damage. The formation and subsequent collapse of vapor bubbles in a flowing liquid, called *cavitation*, is an important fluid flow phenomenon to be given further attention in Chapters 3 and 7.

## 1.9 Surface Tension

At the interface between a liquid and a gas, or between two immiscible liquids, forces develop in the liquid surface that cause the surface to behave as if it were a “skin” or “membrane” stretched over the fluid mass. Although such a skin is not actually present, this conceptual







### V1.5 Floating razor blades

analogy allows us to explain several commonly observed phenomena. For example, a steel needle or razor blade will float on water if placed gently on the surface because the tension developed in the hypothetical skin supports these objects. Small droplets of mercury will form into spheres when placed on a smooth surface because the cohesive forces in the surface tend to hold all the molecules together in a compact shape. Similarly, discrete water droplets will form when placed on a newly waxed surface.

These various types of surface phenomena are due to the unbalanced cohesive forces acting on the liquid molecules at the fluid surface. Molecules in the interior of the fluid mass are surrounded by molecules that are attracted to each other equally. However, molecules along the surface are subjected to a net force toward the interior. The apparent physical consequence of this unbalanced force along the surface is to create the hypothetical skin or membrane. A tensile force may be considered to be acting in the plane of the surface along any line in the surface. The intensity of the molecular attraction per unit length along any line in the surface is called the *surface tension* and is designated by the Greek symbol  $\sigma$  (sigma). Surface tension is a property of the liquid and depends on temperature as well as the other fluid it is in contact with at the interface. The dimensions of surface tension are  $FL^{-1}$  with BG units of lb/ft and SI units of N/m. Values of surface tension for some common liquids (in contact with air) are given in Tables 1.4 and 1.5 and in Appendix B (Tables B.1 and B.2) for water at various temperatures. The value of the surface tension decreases as the temperature increases.

## Fluids in the News


**Walking on water** Water striders are insects commonly found on ponds, rivers, and lakes that appear to “walk” on water. A typical length of a water strider is about 0.4 in., and they can cover 100 body lengths in one second. It has long been recognized that it is *surface tension* that keeps the water strider from sinking below the surface. What has been puzzling is how they propel themselves at such a high speed. They can’t pierce the water surface or they would sink. A team of mathematicians and engineers from the Massachusetts Institute of Technology (MIT) applied conventional flow visualization techniques and high-speed

video to examine in detail the movement of the water striders. They found that each stroke of the insect’s legs creates dimples on the surface with underwater swirling vortices sufficient to propel it forward. It is the rearward motion of the vortices that propels the water strider forward. To further substantiate their explanation the MIT team built a working model of a water strider, called Robostrider, which creates surface ripples and underwater vortices as it moves across a water surface. Waterborne creatures, such as the water strider, provide an interesting world dominated by surface tension. (See Problem 1.49.) ■

Among common phenomena associated with surface tension is the rise (or fall) of a liquid in a capillary tube. If a small open tube is inserted into water, the water level in the tube will rise above the water level outside the tube as is illustrated in Fig. 1.4a. In this situation we have a liquid–gas–solid interface. For the case illustrated there is an attraction (adhesion) between the wall of the tube and liquid molecules, which is strong enough to overcome the mutual attraction (cohesion) of the molecules and pull them up to the wall. Hence, the liquid is said to *wet* the solid surface.

The height,  $h$ , is governed by the value of the surface tension,  $\sigma$ , the tube radius,  $R$ , the specific weight of the liquid,  $\gamma$ , and the *angle of contact*,  $\theta$ , between the fluid and tube. From the free-body diagram of Fig. 1.4b we see that the vertical force due to the surface tension is equal to  $2\pi R\sigma \cos \theta$  and the weight is  $\gamma\pi R^2h$  and these two forces must balance for equilibrium. Thus,

$$\gamma\pi R^2h = 2\pi R\sigma \cos \theta$$




■ **FIGURE 1.4** Effect of capillary action in small tubes. (a) Rise of column for a liquid that wets the tube. (b) Free-body diagram for calculating column height. (c) Depression of column for a nonwetting liquid.

so that the height is given by the relationship

$$h = \frac{2\sigma \cos \theta}{\gamma R} \quad (1.16)$$

The angle of contact is a function of both the liquid and the surface. For water in contact with clean glass  $\theta \approx 0^\circ$ . It is clear from Eq. 1.16 (and shown by the figure in the margin) that the height is inversely proportional to the tube radius. Therefore, the rise of a liquid in a tube as a result of capillary action becomes increasingly pronounced as the tube radius is decreased.



## EXAMPLE 1.7 Capillary Rise in a Tube

**GIVEN** Pressures are sometimes determined by measuring the height of a column of liquid in a vertical tube.

**FIND** What diameter of clean glass tubing is required so that the rise of water at  $20^\circ\text{C}$  in a tube due to a capillary action (as opposed to pressure in the tube) is less than 1.0 mm?

### SOLUTION

From Eq. 1.16

$$h = \frac{2\sigma \cos \theta}{\gamma R}$$

so that

$$R = \frac{2\sigma \cos \theta}{\gamma h}$$

For water at  $20^\circ\text{C}$  (from Table B.2),  $\sigma = 0.0728\text{ N/m}$  and  $\gamma = 9.789\text{ kN/m}^3$ . Since  $\theta \approx 0^\circ$  it follows that for  $h = 1.0\text{ mm}$ ,


$$\begin{aligned} R &= \frac{2(0.0728\text{ N/m})(1)}{(9.789 \times 10^3\text{ N/m}^3)(1.0\text{ mm})(10^{-3}\text{ m/mm})} \\ &= 0.0149\text{ m} \end{aligned}$$

and the minimum required tube diameter,  $D$ , is

$$D = 2R = 0.0298\text{ m} = 29.8\text{ mm}$$

(Ans)

**COMMENT** By repeating the calculations for various values of the capillary rise,  $h$ , the results shown in Fig. E1.7 are obtained. Note that as the allowable capillary rise is decreased, the diameter of the tube must be significantly increased. There is always some capillarity effect, but it can be minimized by using a large enough diameter tube.



■ **FIGURE E1.7**

If adhesion of molecules to the solid surface is weak compared to the cohesion between molecules, the liquid will not wet the surface and the level in a tube placed in a nonwetting liquid will actually be depressed, as shown in Fig. 1.4c. Mercury is a good example of a nonwetting liquid when it is in contact with a glass tube. For nonwetting liquids the angle of contact is greater than  $90^\circ$ , and for mercury in contact with clean glass  $\theta \approx 130^\circ$ .

Surface tension effects play a role in many mechanics problems, including the movement of liquids through soil and other porous media, flow of thin films, formation of drops and bubbles, and the breakup of liquid jets. Surface phenomena associated with liquid–gas, liquid–liquid, liquid–gas–solid interfaces are exceedingly complex, and a more detailed and rigorous discussion of them is beyond the scope of this text. Fortunately, in many fluid mechanics problems, surface phenomena, as characterized by surface tension, are not important, as inertial, gravitational, and viscous forces are much more dominant.

## F l u i d s i n t h e N e w s

**Spreading of oil spills.** With the large traffic in oil tankers there is great interest in the prevention of and response to oil spills. As evidenced by the famous *Exxon Valdez* oil spill in Prince William Sound in 1989, oil spills can create disastrous environmental problems. It is not surprising that much attention is given to the rate at which an oil spill spreads. When spilled, most oils tend to spread horizontally into a smooth and slippery surface, called a slick. There are many factors which influence the ability of an oil slick to spread, includ-

ing the size of the spill, wind speed and direction, and the physical properties of the oil. These properties include *surface tension*, *specific gravity*, and *viscosity*. The higher the surface tension the more likely a spill will remain in place. Since the specific gravity of oil is less than one it floats on top of the water, but the specific gravity of an oil can increase if the lighter substances within the oil evaporate. The higher the viscosity of the oil the greater the tendency to stay in one place. ■

## 1.10 Chapter Summary and Study Guide

*fluid  
units  
basic dimensions  
dimensionally  
homogeneous  
density  
specific weight  
specific gravity  
ideal gas law  
absolute pressure  
gage pressure  
no-slip condition  
absolute viscosity  
Newtonian fluid  
kinematic viscosity  
bulk modulus  
speed of sound  
vapor pressure  
surface tension*

This introductory chapter discussed several fundamental aspects of fluid mechanics. Methods for describing fluid characteristics both quantitatively and qualitatively are considered. For a quantitative description, units are required, and in this text, two system of units are used: the British Gravitational (BG) System (pounds, slugs, feet, and seconds) and the International (SI) System (newtons, kilograms, meters, and seconds). For the qualitative description the concept of dimensions is introduced in which basic dimensions such as length,  $L$ , time,  $T$ , and mass,  $M$ , are used to provide a description of various quantities of interest. The use of dimensions is helpful in checking the generality of equations, as well as serving as the basis for the powerful tool of dimensional analysis discussed in detail in Chapter 7.

Various important fluid properties are defined, including fluid density, specific weight, specific gravity, viscosity, bulk modulus, speed of sound, vapor pressure, and surface tension. The ideal gas law is introduced to relate pressure, temperature, and density in common gases, along with a brief discussion of the compression and expansion of gases. The distinction between absolute and gage pressure is introduced, and this important idea is explored more fully in Chapter 2.

The following checklist provides a study guide for this chapter. When your study of the entire chapter and end-of-chapter exercises has been completed, you should be able to

- write out meanings of the terms listed here in the margin and understand each of the related concepts. These terms are particularly important and are set in color and bold type in the text.
- determine the dimensions of common physical quantities.

- determine whether an equation is a general or restricted homogeneous equation.
- use both BG and SI systems of units.
- calculate the density, specific weight, or specific gravity of a fluid from a knowledge of any two of the three.
- calculate the density, pressure, or temperature of an ideal gas (with a given gas constant) from a knowledge of any two of the three.
- relate the pressure and density of a gas as it is compressed or expanded using Eqs. 1.11 and 1.12.
- use the concept of viscosity to calculate the shearing stress in simple fluid flows.
- calculate the speed of sound in fluids using Eq. 1.14 for liquids and Eq. 1.15 for gases.
- determine whether boiling or cavitation will occur in a liquid using the concept of vapor pressure.
- use the concept of surface tension to solve simple problems involving liquid–gas or liquid–solid–gas interfaces.

## Review Problems

Go to Appendix F for a set of review problems with answers. Detailed solutions can be found in *Student Solution Manual for a Brief Introduction to Fluid Mechanics*, by Young et al. (© 2006 John Wiley and Sons, Inc.).

## Problems

**Note:** Unless specific values of required fluid properties are given in the statement of the problem, use the values found in the tables on the inside of the front cover. Problems designated with an (\*) are intended to be solved with the aid of a programmable calculator or a computer. Problems designated with a (†) are “open-ended” problems and require critical thinking in that to work them one must make various assumptions and provide the necessary data. There is not a unique answer to these problems.

Answers to the even-numbered problems are listed at the end of the book. Access to the videos that accompany problems can be obtained through the book’s web site, [www.wiley.com/college/young](http://www.wiley.com/college/young). The lab-type problems and FE problems can also be accessed on this web site.

### Section 1.2 Dimensions, Dimensional Homogeneity, and Units

**1.1** Verify the dimensions, in both the *FLT* and *MLT* systems, of the following quantities, which appear in Table 1.1: (a) angular velocity, (b) energy, (c) moment of inertia (area), (d) power, and (e) pressure.

**1.2** Determine the dimensions, in both the *FLT* system and *MLT* system, for (a) the product of force times volume, (b) the product of pressure times mass divided by area, and (c) moment of a force divided by velocity.

**1.3** If  $V$  is a velocity,  $\ell$  a length, and  $\nu$  a fluid property having dimensions of  $L^2T^{-1}$ , which of the following combinations are dimensionless: (a)  $V\ell\nu$ , (b)  $V\ell/\nu$ , (c)  $V^2\nu$ , (d)  $V/\ell\nu$ ?

**1.4** Dimensionless combinations of quantities (commonly called dimensionless parameters) play an important role in fluid

mechanics. Make up five possible dimensionless parameters by using combinations of some of the quantities listed in Table 1.1.

**1.5** The volume rate of flow,  $Q$ , through a pipe containing a slowly moving liquid is given by the equation

$$Q = \frac{\pi R^4 \Delta p}{8 \mu \ell}$$

where  $R$  is the pipe radius,  $\Delta p$  the pressure drop along the pipe,  $\mu$  a fluid property called viscosity ( $FL^{-2}T$ ), and  $\ell$  the length of pipe. What are the dimensions of the constant  $\pi/8$ ? Would you classify this equation as a general homogeneous equation? Explain.

**1.6** The pressure difference,  $\Delta p$ , across a partial blockage in an artery (called a *stenosis*) is approximated by the equation

$$\Delta p = K_v \frac{\mu V}{D} + K_u \left( \frac{A_0}{A_1} - 1 \right)^2 \rho V^2$$

where  $V$  is the blood velocity,  $\mu$  the blood viscosity ( $FL^{-2}T$ ),  $\rho$  the blood density ( $ML^{-3}$ ),  $D$  the artery diameter,  $A_0$  the area of the unobstructed artery, and  $A_1$  the area of the stenosis. Determine the dimensions of the constants  $K_v$  and  $K_u$ . Would this equation be valid in any system of units?

**1.7** According to information found in an old hydraulics book, the energy loss per unit weight of fluid flowing through a nozzle connected to a hose can be estimated by the formula

$$h = (0.04 \text{ to } 0.09)(D/d)^4 V^2 / 2g$$

where  $h$  is the energy loss per unit weight,  $D$  the hose diameter,  $d$  the nozzle tip diameter,  $V$  the fluid velocity in the hose, and  $g$